




Kom igång med
ConnectAlarm
appen





Börja med att ladda ner och installera ConnectAlarm appen på din Iphone eller Android.





END USER LICENSE AGREEMENT

PowerSeries Connect Alarm app

IMPORTANT NOTICE: This End User License Agreement ("Agreement") is a binding legal contract between you ("you") and Visonic Ltd. and Tyco Safety Products Canada Ltd., both being subsidiaries of Johnson Controls International plc. ("JCI", "we", or "us"). By downloading, installing, accessing or using the accompanying software (the "Software") you will be bound by the terms of this Agreement. If you do not agree to the terms of this Agreement, JCI is not willing to grant you any right to use or access the Software. In such event, you may not download, install, access, use or copy the Software. If this agreement is being agreed to by you or other legal entity, then the person agreeing to this agreement on behalf

Acceptera

Läs igenom och scrolla till slutet.



Telenor SE 16:43

Slutanvändar avtal

rights of access, rectification, cancellation and opposition by writing to JCI corporate address stated above, or by sending an e-mail to at visonic.alert.support@tycoint.com accompanying the request with a copy of an official identifying document. JCI shall be the exclusive owner of all Data. JCI shall have the right to de-identify your Data so that it does not identify you directly or by inference (the "De-Identified Data"). JCI shall have the right and ability to use the De-Identified Data for its business purposes, including improvement of the Software, research, product development, product improvement and provision of products and services to JCI's other customers (collectively, "JCI's Business Purposes").

☒ Jag accepterar slutanvändaravtalet

Acceptera

Kryssa i rutan
"Jag accepterar
slutanvändaravtalet"
och tryck "Acceptera"



Telenor SE 16:43

Sekretessmeddelande

Privacy Notice:

- Johnson Controls as Data Controller processes Personal Data to allow this App to function. The Personal Data processed by Johnson Controls as Data Controller are:
 1. Security Panel ID
 2. Security Panel SIM card ID (if present)
 3. User mobile number (entered via security panel)
 4. User email (entered via security panel)
 5. User & Installer passwords (encrypted)

☐ Jag accepterar sekretessmeddelandet

Acceptera

Scrolla till slutet av
”sekretessmeddelandet”



Telenor SE 16:43

Sekretessmeddelande


event. You are the Data Controller of the Personal Data collected by the Interactive Functionality from the Product at your location and, as such, are obligated to learn about and comply with all applicable local, state/provincial and federal/national laws and regulations pertaining to personal data protection, privacy and security, including but not limited to: (i) any laws relating to the recording or sharing of video or audio content that includes third parties, or (ii) any laws requiring notice to or consent of third parties with respect to your use of security cameras and video in connection with the Interactive Functionality.

☒ Jag accepterar sekretessmeddelandet

Acceptera

Kryssa i rutan
"Jag accepterar
sekretessmeddelandet"
och tryck "Acceptera"





Fyll i serveradressen:
visonic.stl.nu
och tryck "OK"



Telenor SE 16:44

ConnectAlarm

Server
visonic.stl.nu [Ändra](#)

E-post

Lösenord [Glömt?](#)

☐ Kom ihåg lösenord

LOGGA IN

Registrera dig!

Har du redan en e-post kod?

Är det första gången du använder ConnectAlarm appen?
Tryck "Registrera dig!"
utan att fylla i mer på denna sida.



Telenor SE 16:46

ConnectAlarm



@

Ange e-postadress

Behörighetskod skickas

E-post

REGISTRERA DIG

< Åter till inloggning

Fyll i den e-postadress du vill använda för att registrera dig och använda som inloggningskonto för denna app. OBS, säkerställ att du har tillgång till denna e-post innan du går vidare. Tryck "Registrera dig"





Telenor SE 16:46

ConnectAlarm



Kolla e-post!

Vi har skickat e-post med aktiveringskod!

E-post kod

FORSSÄTT

< Åter till inloggning

En aktiveringskod har skickats till din e-post.

Gå till din inkorg och kopiera aktiveringskoden samt klistra in här. OBS, aktiveringskoden kan hamna i skräpposten om den inte kommer till din inkorg.

Tryck "Fortsätt"



Telenor SE 16:47

ConnectAlarm



✓

Ditt konto är aktiverat

Ange lösenord för ditt konto

Lösenord

Repetera lösenord


FORSSÄTT

Välj det lösenord du vill koppla till ditt konto.

OBS, Lösenordet måste bestå av minst 8 tecken och innehålla minst 1 bokstav, 1 siffra samt ett specialtecken, ex ! Eller ?

Repetera lösenordet och tryck "Fortsätt"





The screenshot shows the 'ConnectAlarm' app interface on a mobile device. At the top, the status bar shows 'Telenor SE', signal strength, Wi-Fi, and the time '16:48'. The app header is blue with the 'ConnectAlarm' logo and a Swedish flag icon. Below the header is a large blue circle with a white plus sign. The main heading is 'Lägg till panel' (Add panel). Below it is the instruction 'Ange din panelinformation' (Enter your panel information). There are three input fields: 'Panelnamn' (Panel name) with a hint 'vänligen namnge din panel' (please name your panel), 'Panel serienummer' (Panel serial number), and 'Master användarkod' (Master user code). At the bottom is a white button with the text 'ANSLUT' (Connect).

Fyll i ditt Panel ID på första och andra raden.

Ditt Panel ID består av 6st tecken och överlämnades vid installationen.


Saknar du ditt Panel ID, kontakta Svenska Trygghetslösningar via kundservice@stl.nu

På nedersta raden fyller du i din Master användarkod.

(Fyrsiffrig kod, samma som i knappsatsen vid dörren)

Tryck "Anslut"





Nu ska du kunna se
ditt larmsystem i
panel listan.
Tryck på panelen för
att komma vidare



Telenor SE 15:43

<



Låser upp 1B9317

Ange användarkod

....|

FORSSÄTT

1	2 ABC	3 DEF
4 GHI	5 JKL	6 MNO
7 PQRS	8 TUV	9 WXYZ
,	0	

Ange din fyrsiffriga kod.
Samma som i
knappsatsen vid dörren.
Tryck "Fortsätt"





Nu är du inloggad på ditt larmsystem.

* Är ditt larm uppkopplat via bredbandet ansluts din panel automatiskt till appen.

* Är ditt larm endast uppkopplat via GPRS behöver du ansluta genom att trycka högst upp till höger och ansluta manuellt.





Nu kan du börja styra ditt larmsystem

För mer information om hur man använder appen och vilka funktionerna som finns, besök vår hemsida på stl.nu/app-guide

